

BrookeTel TV Amigo 7X Remote Guide

1. Change between your possible input options.
(ex. HDMI 1 to HDMI 2)
2. Turns TV ON/OFF
3. These are non-functioning buttons
4. Non-functioning
5. These are quick clicks buttons while viewing anything on CloudPVR or On Demand
6. Quick click to your downloaded apps (eg. Weather Network)
7. These are your directions for the guide(s) and the OK button (middle button)
8. This will take you BACK a step
9. Volume Up and Down
10. Used for entering channel numbers
11. To get the information on the program you have selected
12. This is the Search feature. You use this to manually search for a program/actor/title etc.
13. The IR Sensor/ Transmitter must be pointed at Set-Top Box for remote to work
14. This is the Microphone to speak into if using speaking features
15. Turns the Set-Top Box ON/OFF
16. Non-functioning
17. Non-functioning
18. Activates the Guide(s)
19. Returns you to the Set-Top Box Home page
20. Activates the microphone to give commands
21. Channel UP and DOWN
22. Mutes the volume
23. Subtitles (ON/OFF) controls
24. Returns you to the last channel viewed
25. This will illuminate when batteries are LOW

